



Contact Awoco Tech Support at
626-522-9688, sales@awoco.com

In Attic

- Step 6. Plan the ducting path and mount the Blower unit to the stud / lumber securely in the attic.
- Step 7. Use the duct tapes, connect the ducts to the top and bottom of the vent adapters on the Blower unit.
- Step 8. According to the wire colors, connect the speed wires again (refer to Step 4). Extend the wires if needed while making sure the colors matched.
- Step 9. Ground the Blower unit with a Ground wire to a chassis screw on the Blower unit.

In Kitchen

- Step 10. Mount the Control unit's circuit box to inside the hood or on wall; the control panel on the hood front or wall; place the LED lights properly.
- Step 11. Check all duct connections and electrical connections again. Then plug in power cord and test the installed system.

- Step 1. Remove the screws and open the top connection box. Take out the blow items.
 - The orange color electrical connectors.
 - The mounting screws.
- Step 2. Install the 2 mounting bars.
- Step 3. Install the 2 duct adapters (air inlet and outlet) with gaskets.
 - The 6" vent has a air damper on the top vent.
 - The 8" Blower unit has no air damper included, recommend to install the air damper on roof or wall vent.
- Step 4. **Test before install.**
 - Connect the LED lights, control panel to the Control unit's circuit box.
 - According to the wire colors, use the orange color electrical connectors to connect the speed wires from the Control unit's circuit box to the Blower unit top connection box.
 - Place the Blower unit in safe place, plug in power cord, press the power button and then one of the speed buttons to turn on.
 - Test all speeds and LED lights.
- Step 5. Unplug the power cord and remove the speed wires off the Blower unit.

